

Remote Sensor System  
Switch signal Terminal unit version  
16 signals transmission

Remote terminal : RS16TA-211D-S04, RS16T-211D-S04  
RS16TA-211P-S04, RS16T-211P-S04  
Transmitting head : RSH16T-030-PU-CP-\_\_ , RSH16T-TF030-PU-CP-\_\_  
Output head : RSH16E-030N-PU-\_\_ , RSH16E-TF030N-PU-\_\_  
RSH16E-030P-PU-\_\_ , RSH16E-TF030P-PU-\_\_

#### Attention for Installation

(Read this section thoroughly before installation.)


Before using the Remote Sensor, read this manual carefully.  
During installation and operation, pay close attention to the safety aspect.

- ◆ Ensure the power is switched off during installation or maintenance operations.
- ◆ Use a regulated power supply, e.g. switch-model type.  
Simpler power supplies, such as a full-wave rectification type, will cause the permissible ripple rating to be exceed and may cause malfunction.
- ◆ Ensure correct connections by reference to the wiring diagram.
- ◆ To avoid malfunction caused by induction noise, cable should be kept apart from motor or other power cable.

#### Transmitting head / Output head specification

■ Transmitting head : RSH16T-030-PU-CP-\_\_  
RSH16T-TF030-PU-CP-\_\_

■ Output head : RSH16E-030 □ -PU-\_\_  
RSH16E-TF030 □ -PU-\_\_



A057

Transmitting head	Standard type	Anti-weld slag type
Type code	RSH16T-030-PU-CP-__	RSH16T-TF030-PU-CP-__
Operating distance	2...8 mm	
Center offset	±3 mm	
Connection cable	M12 connector	
Material Housing	Nickel plated brass	Fluorinated resin coated
Operating surface	Nylon 12	Fluorinated resin
Ambient temperature	0...+50 deg.C.	
Protection class	IP 67	

( Note )


Please note that the cable length of an output sensor may not longer than 10m.  
The CE marking verifies that our products comply with the requirements of EMC directive.  
The surge test to an output sensor is not carried out .  
When using an output sensor with cable length longer than 10m, a measure to protect the sensor from surge current should be taken.

◆ Please note that the signal may become unstable (false signal or chattering) when the transmission distance and the center offset are outside the specification range.

◆ The inzone signal is a preliminary signal for confirming that the output signal is established within the specification range. Please note that it does not guarantee signals output outside the specification range.


Typical Transmitting Diagram  
( Supply voltage at 24V/non-flush mount )

RSH16T-030-PU-CP / RSH16E-030 □ -PU  
RSH16T-TF030-PU-CP / RSH16E-TF030 □ -PU



2017.10.31 No.T307702H

#### Construction of the system




#### 【Function of each component】


- Detector SW : Detected signals is transmitted to Remote terminal.
- Remote terminal : DC2W/Mechanical switch or DC3W switch is connected and detected signals is transmitted to Transmission head.
- Transmitting head: Provides power for Detector SW, also passes detected signals from Detector to Output Head.
- Output head : Puts out detected signal to external controller, also sends power for operating of Detector and Transmitter.
- Anti-weld slag type : Fluorine resin cap & Fluorine resin coated housing to protect against weld slag

#### Wiring

■ RSH16E-030N-PU-\_\_ , RSH16E-TF030N-PU-\_\_ (NPN)




■ RSH16E-030P-PU-\_\_ , RSH16E-TF030P-PU-\_\_ (PNP)



#### Remote terminal specification

■ Remote terminal : RS16TA-211D-S04 / RS16TA-211P-S04  
/RS16T-211D-S04 / RS16T-211P-S04



#### Applicable angle connector type (Detector's connector)

When using an angle connector, please use a connector of which key is positioned same as the following figure.

