


2000W ワイヤレス充電システム
電源ユニット専用フィルター

RCS-FILTER02 (旧 RCS2000-OP002)
RCS-FILTER02-SET (旧 RCS2000-OP002-02)

【注意事項】


- ・本製品は 電源ユニットの吸気口に取り付け、粉塵 / ミストを軽減するものであり、完全に防ぐものではありません。
- ・用途以外に使用しないでください。
- ・フィルターは定期的に点検し、目詰まりや劣化が見受けられる場合は、フィルターを交換してください。不織布が汚れると十分な空気を取り込めず、故障や火災の原因となります。
- ・故障の原因になるため、フィルターは切らずに、中央で折って二枚重ねた状態でお使いください。
- ・フィルターは水洗いしないでください。
- ・フィルターの交換に際して、カバーの脱着で過大な力を加えると破損の原因となります。

型式：RCS-FILTER02



RCS2000AC(電源ユニット) の吸気口に取り付ける
専用フィルターです。フィルター交換の際にお使いください。

材質：ポリエステル / ビニロン
数量：1 パック 24 枚入り




*フィルターは切らずに、中央で二つに折って
お使いください。

フィルターの交換方法



- ①カバー角の隙間に指を掛けて適当な力で引っ張り、カバーを外してください。
注意：過度な力を加えると破損の原因となります。
- ②フィルターを新しいものに交換します。
- ③カバーを元にもどしてください。


型式：RCS-FILTER02-SET



RCS2000AC(電源ユニット) の吸気口に取り付けてある
ガード、専用フィルター、カバーのセットです。

取付に使用するねじ：M 4x5 ねじ 4 個

①	ガード	樹脂 (PPE+PS)
②	フィルター	ポリエステル / ビニロン 2.5mm 厚
③	カバー	樹脂 (PPE+PS)



セット内容




Wireless charging system
Filter for 2000W power supply unit only

RCS-FILTER02 (旧 RCS2000-OP002)
RCS-FILTER02-SET (旧 RCS2000-OP002-02)

【Notes】


- This product is attached to the intake port of the power supply unit and is intended to reduce dust/mist, but does not completely prevent it.
- Please do not use it for any purpose other than its intended purpose.
- Inspect the filter regularly and replace it if it is clogged or deteriorated.
If the nonwoven fabric becomes dirty, it will not be able to take in enough air, which may cause malfunction or fire.
- Please do not cut the filter, but fold it in the middle and use it in two layers, as this may cause a malfunction.
- Do not wash the filter with water.
- When replacing the filter, applying excessive force when attaching or removing the cover may cause damage.

Type code : RCS-FILTER02



This is a filter that attaches to the inlet part of RCS2000AC (power supply unit). Please use it when replacing the filter.

Material: Polyester/vinylon
Quantity: 1 pack contains 24 pieces




*Do not cut the filter; fold it in half at the center.

How to replace the filter



- ① Place your finger in the gap between the corners of the cover and pull with appropriate force to remove the cover.
Caution: Applying excessive force may cause damage.
- ② Replace the filter with a new one.
- ③ Replace the cover.


Type code : RCS-FILTER02-SET



Attached to the intake port of RCS2000AC (power supply unit)
A set of guard, special filter, and cover.

Screws used for installation: 4 M4x5 screws

①	guard	resin (PPE+PS)
②	filter	Polyester/vinylon 2.5mm thickness
③	cover	resin (PPE+PS)



set contents

